



Product configuration

Congratulations on purchasing the **EUROLAMP** Wi-Fi Smart Socket. Now you can turn your power on and off manually or according to your schedule through the **EUROLAMP Smart** app installed on your device from anywhere where you have an internet connection. The app also allows you to monitor your power consumption in real time. Good for the environment.

Specifications

Maximum current	16A
Input voltage	AC (220~240)V
Max.Load power	3680 W
Wireless Type	WiFi 2.4 GHz
Controls	Manual ON/OFF
Operating temperature	(-20~+50°C)
Operating humidity	(0~95) % RH non condensing

1

Configuration Preparation

1.Download the smart phone application by scanning the QR Code or searching for **EUROLAMP Smart** in the Apple App Store for iPhones, or Google Play for Android phones.



IOS / Android App EUROLAMP Smart app

2

2. Launch the app and log in. New users will need to register a new account.



3. Plug the Wi-Fi Smart Socket into a mains outlet and turn on the outlet power switch. The LED should be green.


Where Not to Install Your Wi-Fi Smart Socket

Do not install the Wi-Fi Smart Socket in wet or damp areas such as bathrooms and laundries.

3

CONFIGURATION

Press the on/off button on the Wi-Fi smart socket. The LED will rapidly flash green.




Note: If the LED does not flash, try resetting the device (see Reset below).

4

Auto Scan


Under LED flash green and blueooth works, conection automatically when open **EUROLAMP Smart app**.



5

Enter password

Search for the Wi-Fi hotspot and enter the hotspot password.




Tap **Next**. Observe that the device is connecting to the application.

Add Manually:
If Bluetooth is not available

6


Set up the device.



7

Enter password

Search for the Wi-Fi hotspot and enter the hotspot password.




Tap **Next**. Observe that the device is

8

Reset

If the Wi-Fi smart socket fails to respond to commands, it may need to be reset.

1. Unplug the Wi-Fi smart socket from the mains outlet.
2. Plug the device back into the mains outlet and turn on the outlet power switch.
3. Press and hold the Manual Control Button until the LED indicator flashes quickly (between 5 s and 10 s).
4. Follow the steps above in **Configuration** to set up the device.



Change Device Name

1. Tap **Device List** to see a list of connected devices.

10

Share Devices

1. In **Profile**, tap **Device Sharing**.
2. Tap **Add**.
3. Select the device to share.
4. Enter the telephone number or email address of the person you want to share with.
5. Tap **Confirm**.

Schedule

Schedules can be added to turn devices on or off at preset times and days of the week. The schedules can be once or repeat on certain days of the week.

To activate a schedule:

1. From the **Devices** screen, tap the **Smart Socket**, then select **Schedule**.

11

Metering

press Electic to set meter.



12

Care and Maintenance Firmware Update

New features may be added to the firmware embedded in your Wi-Fi smart socket.

1. Tap **Info**.
2. Tap **Check for Firmware Update**.

Remove Device

1. To remove the device from the application list, tap **Info (...)** at the upper right-hand corner of the application.
2. Tap **Remove Device** to remove the device.

CORRECT DISPOSAL OF THE PRODUCT
Recycling indicates that this product should not be disposed with other household waste throughout the EU. To prevent possible harm to the environment or human health, please dispose of waste correctly. It is important to promote the sustainable reuse of material resources. To ensure your waste disposal, please use the return and collection system or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

EUROLAMP
IMPORTED IN EU BY EUROLAMP SA:
KAMPOS DRAVATA - KINIA / 570 08 / THESSALONIKI - GREECE / T: +30 2310 574802
MADE IN CHINA
info@eurolamp.gr / www.eurolampglobal.com

